



dōTERRA® Bubble

Motion-Activated Diffuser


Instruction Manual

v2


Overview




Instructions For Use




1. Remove the Cover.



2. Secure the Cover on the Cover Holder at the bottom of the Diffuser.




3. Turn the diffuser upside down and insert a 5 mL or 15 mL essential oil bottle into the Bottle Screw-thread. Turn clockwise to tighten. Note: Do not remove the orifice reducer prior to inserting bottle.



4. Turn the diffuser upright. Toggle the Mode Switch to start the diffuser.

Functions



Normal Mode

Toggle the Mode Switch to the left to select Normal Mode—the Indicator Light will turn blue. The diffuser will spray 7 bursts, then hibernate for 3 minutes. After 3 minutes, each time the Motion Sensor detects movement, the diffuser will spray 3 bursts, then hibernate for 3 minutes. Toggle the Mode Switch back to center position to turn off the diffuser.

High Mode

Toggle the Mode Switch to the right to select High Mode—the Indicator Light will turn green. The diffuser will spray 10 bursts, then hibernate for 3 minutes. After 3 minutes, each time the Motion Sensor detects movement, the diffuser will spray 4 bursts, then hibernate for 3 minutes. Toggle the Mode Switch back to center position to turn off the diffuser.

Battery Recharge

Battery Drained Protection: When the battery power becomes too low, the Indicator Light flashes red three times and the diffuser will automatically shut off completely.

1. Plug the provided USB cable into the Micro USB Socket and connect to a power source.
2. The Indicator Light turns red while charging and turns off when fully charged.
3. Run time for each full recharge is approximately 12 hours - based on activated spray time.
4. Charging time is approximately 4 hours from drained to full charge with 1Amp Power Adapter.

Important: As with most lithium-ion batteries, the device battery life will gradually decrease over time. After about 300 charge cycles, the device battery life will decrease to about 80 percent compared to the battery on a new device. This is normal and does not represent an issue with the device or with the battery.

Features

1. Dimensions: 46 x 46 x 75.5mm / 1.82 x 1.82 x 2.98 in
2. Material: PP
3. Suggested Room Size: 10 sq.m / 110 sq. ft
4. Motion Sensor Range: 4 meter / 13 feet, 120 degree field of view
5. Power Source: DC 5V 1A and 3.7V 800mAh battery

Cautions

1. It is normal for mist volume to vary with the type of essential oil used.
2. Use of chemical fragrances, spices, or impure essential oils may cause product damage.
3. Essential oils with high viscosity may cause the diffuser not to mist properly. If the diffuser has difficulty misting the essential oil, follow "Cleaning and Maintenance" to clean away the essential oil from the Oil Tank.
4. It is recommended to leave the essential oil bottle in the diffuser until completely dispensed and the diffuser stops spraying. Changing the essential oil bottle before this will cause the oil to spill.
5. The Cover is not leak-proof. If essential oil is left inside the Oil Tank, essential oil may leak when the diffuser is stored at an angle even with the Cover secured over the Oil Tank.

Safety

Please follow the safety rules below while using the product:


1. Only use the diffuser for the intended purpose.
2. Use only the USB Cable included in the package or wall plug adapter sold separately.
3. When storing the diffuser or relocating it, turn the power off, unplug the device, empty the Oil Tank, and clean the device. Securely replace the Cover over the Oil Tank.
4. Turn off the diffuser and unplug immediately if there is any smoke or burning smell.
5. Do not fill essential oil directly into the Oil Tank to avoid spillage. Always insert a 5 mL or 15 mL essential oil bottle into the Bottle Screw-thread and turn clockwise to tighten securely.
6. Place the diffuser on a flat and solid surface instead of uneven and/or unstable ones like carpets or rugs etc.
7. Do not move the diffuser during its operation. Pull the USB plug instead of the cable to unplug.
8. Do not use this diffuser near water.
9. Do not place the diffuser in direct sunlight or close to a refrigerator, a fan, or other hot environment.
10. This diffuser should not be operated by children unless supervised by an adult.
11. This diffuser is not for medical purposes.

DO NOT inhale the mist directly from the diffuser.


KEEP OUT OF REACH OF CHILDREN

Cleaning and Maintenance


Clean the Mist Plate with a cotton swab and warm water at least twice a week.




Clean the diffuser each time a bottle of essential oil is used up. Before cleaning, turn the diffuser off and unplug the USB Cable.




1. Keep the diffuser upright. Turn counter-clockwise to remove the essential oil botttle.




2. If there is essential oil left inside the Oil Tank, carefully empty the essential oil from the opposite side of the Mist Plate.




3. Fill an empty essential oil bottle with 2 mL/0.07 fl. oz of 3 parts vinegar and 7 parts water.



4. Turn the diffuser upside down and insert the 5 mL or 15 mL essential oil bottle with the suggested cleaning solution into the Bottle Screw-thread. Turn clockwise to tighten.




5. Turn the diffuser upright. Place the diffuser in an open space with good air flow and toggle the Mode Switch to High Mode until it no longer sprays mist.




6. Keep the diffuser upright. Turn counter-clockwise to remove the empty essential oil bottle.

For prolong storage after cleaning:



1. Remove the Cover on the Cover Holder at the bottom of the Diffuser.



2. Securely replace the Cover over the Oil Tank.

Warning:
1. **Use of corrosive or harsh chemicals may cause damage. Essential oil should not come in contact with the exterior surface of the unit.**
2. **Clean the diffuser in open space with good air flow and away from hot environment or heat sources.**

Troubleshooting

Status	Cause(s)	Solution(s)
Startup Failure/ Early Shutdown	1. Improper power cable connection. 2. Battery not charged	1. Unplug the USB Cable and reset carefully. 2. Charge the battery.
No mist or abnormal mist	1. Essential oil of high viscosity used.	1. Please follow the instructions on cleaning and maintenance to clean the essential oil from the Oil Tank.
	1. Oil contamination on Mist Plate.	1. Please follow the instructions on cleaning and maintenance.
	1. Motion sensor detects no motion movement	1. Ensure motion is within 4 meter / 13 feet range and 120 degree field of view.
Oil Leakage	1. Essential oil bottle not tightened securely. 2. Essential oil is left inside the Oil Tank and diffuser stored at angle.	1. Secure the essential oil bottle tightly. 2. Follow the instructions on cleaning and maintenance to clean the essential oil from the Oil Tank.

Product Warranty

dōTERRA® One (1) Year Limited Warranty. dōTERRA's warranty obligation for this product is limited to the terms set forth below: dōTERRA International, LLC ("dōTERRA") warrants this diffuser against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original end-user purchaser ("Warranty Period") provided the operation and maintenance strictly follow the instruction manual. If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, dōTERRA will either (1) ship a new replacement diffuser to original end-user, or (2) issue a refund based on the dōTERRA 30-day return policy. When a replacement or refund is given, the diffuser for which the replacement or refund is provided must be returned to dōTERRA prior to replacement or refund and becomes dōTERRA's property. Please call 1-800-411-8151 for more information.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.This appliance can be used by children ages 8 years and above and persons with reduced physical, sensory or mental capabilities if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and user maintenance should not be made by children without supervision.

This device complies with part 18 of the FCC Rules

(a) The interference potential of device or system:

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

(b) Maintenance of the system:

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

(c) Simple measures that can be taken by the user to correct interference:

NOTE: This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

model number: DT054M

Manufactured for: **dōTERRA INTL, LLC**
389 S 1300 W, Pleasant Grove, UT 84062 USA